




**CONGRATULATIONS**


# Installation and Usage

## Lighting Placement



- **ALWAYS** center light shell over aquarium
- **ALWAYS** mount legs on the outside of the aquarium frame.  
If needed you can remove legs and position light directly on top of the glass canopy.
- **ALWAYS** use over a clear canopy to prevent damage to lights, electronics, or blockage of light due to hard water stains.

## Adjusting Mounting Legs



Flexible mounting legs are stylish and adjustable for flexibility across several aquarium widths.

Aquarium LED 18 – flexible on aquariums 18-24" wide  
Aquarium LED 24 – flexible on aquariums 24-36" wide  
Aquarium LED 36 – flexible on aquariums 36-48" wide  
Aquarium LED 48 – flexible on aquariums 48-60" wide

## Three Mode On/Off Switch

Convenient side mounted three mode On/Off switch. Allows you to provide a variety of lighting profiles including daytime, lunar and off positions.

- II for daytime lights (blue and white),
- 0 for off,
- I for night time (blue only)


## Plugging Light In

In order to power the lights, plug in power adapter to power input on light next to On/Off switch.



# Parts Diagram & Identification

**Mounting Legs**



**Power Adapter**



## Replacement Parts

KEY	ITEM DESCRIPTION FITS	LED LIGHT SIZE	ITEM NO.
1	Mounting Legs (1 Set)	18" - 24" & 24" - 36"	ML19515
1	Mounting Legs (1 Set)	36" - 48"	ML19516
2	Power Adapter	18" - 24" & 24" - 36"	ML90508
2	Power Adapter	36" - 48" & 48" - 60"	ML19517

**Questions or Missing Parts: Call Customer Service (800) 322-1266**

(M-F 7:30 am - 5:30 pm Eastern Time)


## IMPORTANT SAFEGUARDS

**WARNING:** To guard against injury, basic safety precautions should be observed, including the following.

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS

**DANGER:** Since water is employed in the use of aquarium equipment, special care should be taken to avoid electric shock. For each of the following situations, do not attempt to repair the appliance yourself. Return it to an authorized service facility for service, or discard it.

1. A. If the appliance falls into the water, do not reach for it. First unplug it and then retrieve it.  
B. If electrical components of the appliance get wet, unplug the appliance immediately.  
C. Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to get wet.  
D. Do not operate any appliance if it has a damaged cord or plug, if it is malfunctioning, or if it has been dropped or damaged in any manner.  
E. To avoid the possibility of water dripping onto the appliance plug or outlet, position aquarium stand and tank to one side of a wall-mounted outlet. A “drip loop” (see illustration) should be arranged for each cord connecting an aquarium appliance to an outlet. The “drip loop” is the part of the cord below the level of the outlet (or extension cord connector) that prevents water from traveling along the cord to the outlet. If the plug or outlet gets wet, do not unplug the cord. Disconnect the fuse or circuit breaker that supplies power to the appliance. Then unplug the appliance and examine the outlet for presence of water.
2. Close supervision is necessary when any appliance is used by or near children.
3. To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, etc.



4. Always unplug an appliance from an outlet when it is not in use, before putting on or taking off its parts, and before cleaning it. Never yank cord to pull plug from outlet. Grasp the plug and pull to disconnect.
5. If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for fewer amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
6. Do not use an appliance for other than its intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
7. Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing.
8. Make sure the appliance is securely mounted on aquarium before operating it.
9. This appliance was designed for use over a glass aquarium cover or acrylic top.  
DO NOT USE OVER "OPEN" WATER.

**SAVE THESE INSTRUCTIONS**

# Clean and Care Guide

**For maximum light output it is important to keep the clear plastic LED cover clean. Below are a few tips to remember when cleaning your light:**

- Always unplug your LED light while cleaning.
- When cleaning please take care and use a soft cloth to avoid scratching the clear plastic LED cover. Scratches will cause the output from the light to diminish.
- Household vinegar (5-6% acetic acid vinegar solution) will remove most deposits that have formed on the underside of the housing.
- Always apply the solution to the soft cloth then wipe down the light. Never apply the solution directly to the light.
- Refrain from using household cleaners that contain ammonia or bleach when cleaning your light. These can damage the light and may cause problems in your aquarium.

# Troubleshooting Guidelines and Tips

**IMPORTANT:** Always unplug any LED Lighting System before inspecting or disassembling for any reason. It is recommended to use an UL approved power strip with surge protection when operating this light.

**If the lights stop working:**

- Double check that both the adapter and power plug are securely plugged into light and wall socket.

**If light still does not function:**

- Please contact customer service at (800) 322-1266.

**LIMITED WARRANTY** Within one year from the date of original purchase, United Pet Group, Inc. will repair or replace, at its option, any LED Single Bright Lighting System which is deemed defective in workmanship or materials. If you need to return the unit, please call us at 800-322-1266 to request a return authorization and shipping address. Please then return the unit with the proof of the date of purchase.

Damage or injuries resulting from negligence or misuse are not covered by this warranty. Incidental or consequential damages are specifically excluded\*. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

\*Because some states do not allow the exclusion of incidental or consequential damages, this exclusion may not apply to you.

**Customer Service: (800) 322-1266**

(M-F 7:30 am - 5:30 pm Eastern Time)



United Pet Group, Inc. (UPG)

7794 Five Mile Road, Suite 190

Cincinnati, OH 45230

1.800.322.1266 • [www.marineland.com](http://www.marineland.com)

© 2013 UPG

®Registered Trademark of United Pet Group, Inc.









**DISCARD THIS PIECE**

 **CUT HERE**

**DISCARD THIS PIECE**

**CUT HERE** 