

REMINGTON®

DURABLADE PRO

**USE & CARE
MANUAL**

PLEASE READ
PRIOR TO USE



To register your product go to
remington-products.com.au
remington.co.nz

5 YEAR WARRANTY

MB061AU

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be observed, including the following.

READ ALL INSTRUCTIONS BEFORE USING

WARNING: TO REDUCE THE RISK OF BURNS, ELECTROCUTION AND FIRE OR INJURY TO PERSONS

DANGER: AS WITH MOST ELECTRICAL APPLIANCES, ELECTRICAL PARTS ARE ELECTRICALLY LIVE EVEN WHEN THE SWITCH IS OFF.

- This appliance is suitable for use in bath or in the shower.
- This appliance should not be used by children or other persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Keep the appliance and the USB charging cable away from the edge of table or countertops and out of reach of children and persons with reduced physical, sensory or mental capabilities.
- This appliance is not a toy. Children shall be supervised to ensure they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Never operate this appliance if it is damaged, not working correctly or has broken trimming unit as injury may occur.
- Never operate this appliance if the USB charging cable has been damaged or dropped into water.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Remington.
- Do not use outdoors or where aerosol (spray) products are being used, or oxygen is being administered.
- This appliance should never be left unattended when plugged into a power outlet, except when charging.
- Remove appliance from USB port immediately after charging.
- Do not plug or unplug the appliance with wet hands.
- Unplug and switch off this appliance before cleaning it.
- Do not wrap the USB charging cable around the appliance.
- Keep the USB charging cable away from heated surfaces.
- Always store the USB charging cable in a moisture-free location.
- Do not use on people who are asleep.
- For household use only.
- This appliance is supplied with a USB charging cable for charging via standard USB ports, with a power requirement of 5.0V DC 500mA input.

Remington strongly recommends that an approved Safety Switch (residual current device) be installed to protect all bathroom power outlets. Ask an electrical contractor for advice.

SAVE THESE INSTRUCTIONS

MB061AU DURABLADE PRO

USE AND CARE MANUAL

Thank you for purchasing your Remington® DuraBlade Pro. Inside this manual you will find instructions on using and caring for your groomer.



KEY PARTS

- | | |
|---------------------------------------|--------------------------------------|
| 1. On/Off switch | 6. Detail trimmer head |
| 2. Trimmer head | 7. 4 x Snap on combs (1, 2, 4 & 6mm) |
| 3. 39mm blade | 8. USB charging cable |
| 4. Charging pins | 9. Cleaning brush (not shown) |
| 5. LED charging indicator (not shown) | |

NOTE: The 4 snap on combs have different length settings. When first becoming familiar with your DuraBlade Pro, begin with a higher numbered setting. Adjust cutting length, as desired.

ABOUT YOUR GROOMER

MB061AU SPECIFICATIONS

Power System	Cordless (USB Rechargeable)
Full Charge Time	4 Hours
Runtime	60 Minutes
Indicators	LED Charging Indicator
Voltage Type	5.0V DC 500mA input

CHARGING

NOTE: It is recommended to fully charge your appliance before using for the first time. Please refer to the charge times shown on the specifications table above.

- Ensure the product is switched off.
- Connect the product to the USB cable and then connect the USB end of the cable to a powered USB port.

CHARGE LEVEL INDICATOR

Charge Level	Indicator
Charging	LED is solid
Full charge	LED will turn off

- Cordless run time when fully charged is up to 60 minutes.
- Charge time from empty is 4 hours.

NOTE: To preserve the life of your battery, let it run out every 6 months then fully charge.

HOW TO USE

- Switch the product on by pressing the On/Off button.
- Always comb your beard or moustache with a fine comb before you start trimming.

ATTACHING AND REMOVING THE COMBS

- Select the desired trimming length comb. Place the comb over the top of the blade and gently push this down onto the blade until it clicks into place.
- To remove the comb, grasp the comb and pull firmly upwards and away from the groomer.

REMOVING AND ATTACHING THE TRIMMER HEADS

- To remove: Turn the trimmer head anti-clockwise until it clicks, and then lift the trimmer head away from the groomer.
- To attach: Place the trimmer head on the groomer and turn clockwise until it clicks into place.

BEARD TRIMMING

- Select your desired trimming length comb. If you are trimming for the first time start with the maximum trimming length setting.
- Turn the groomer on.
- Place the flat top of the fixed comb against the skin.
- Slowly slide through the hair, against the direction of growth. Repeat from different directions as necessary.
- If hair builds up in the trimmer comb during the trimming process, switch the groomer off, pull off the comb and brush the hair off.

TO GET A CLEAN SHAVEN LOOK

- To trim any length of beard or stubble hair for a clean, shaven look then follow the above steps without a comb attached to the blade head.
- Place the flat top of the blade against the skin and slowly slide through the hair against the direction of growth.

TRIMMING AND EDGING

- Hold the groomer with the back side of the blade facing you with no combs attached.
- Start with the blades resting lightly against your skin and motion the blade towards the edge of your beard line to trim the desired facial hair.
- Shape as desired.

DETAIL TRIMMING

- Use the Detail Trimmer for precise detail trimming and styling in tight, small areas such as moustache and sideburns.
- Hold the groomer with the back side of the blade facing you.
- Start with the blades resting lightly against your skin and motion the blade towards the edge of your facial hair to trim the hair.
- Shape as desired.

WET TRIMMING USING SHAVING GEL OR FOAM

- Follow the same instructions as dry shaving if using shaving gel or foam.

NOTE: After use with shaving gel, please rinse the blade under warm water to clean away any excess gel or foam.

CLEANING & MAINTENANCE

- To ensure long lasting performance of the groomer, clean after each use.
- The easiest and most hygienic way to clean the groomer is by rinsing the head under the tap after use while the groomer is on.
- You can also use the cleaning brush provided to remove any hair clippings.
- To keep the groomer in optimal condition we recommend re-oiling the blades after cleaning. Place a few drops of cutter or sewing machine oil onto the blades. Wipe off excess oil.

NOTE: Always clean the attachments regularly to ensure maximum performance and a proper operating life.

ACCESSORY ORDER FORM

Article	Part No.	Price each AUD	Price each NZD	Qty	Amount
Spare Trimmer Head 39mm*	SPH39-MB061AU	\$34.95 AUD	\$39.95 NZD		\$
Spare Trimmer Head 12mm*	SPH12-MB061AU	\$34.95 AUD	\$39.95 NZD		\$
Spare Snap on Combs Set (1, 2, 4 & 6mm)	SPC-MB061AU	\$14.95 AUD	\$19.95 NZD		\$
Spare USB Charging Cable	SPUSB-MB061AU	\$9.95 AUD	\$14.95 NZD		\$
IMPORTANT: Pricing in effect at time of publication, inclusive of GST. Subject to change without notice. Postage & handling \$7.50 standard for Australia & New Zealand.					\$
For help or to place an order on the phone call Remington Customer Service:					\$ 7.50
① Australia: 1800 623 118 (toll free)					\$
② New Zealand: 0800 736 776 (toll free)					

* The DuraBlade trimmer head is guaranteed to last for the entire warranty period as communicated in the warranty details. In the extremely unlikely event that your blade becomes blunt, please contact your local Remington Service centre who will provide you with a replacement.

REMINGTON®

Remington is a Registered Trademark of Spectrum Brands, Inc., or one of its subsidiaries.



MAIL YOUR ORDER FORM TO:

AUSTRALIAN RESIDENTS:

Spectrum Brands Australia Pty Ltd
Locked Bag 3004
Braeside, VIC 3195
Australia

NEW ZEALAND RESIDENTS:

Spectrum Brands New Zealand Pty Ltd
PO BOX 9817
Newmarket, 1149, Auckland
New Zealand

TROUBLESHOOTING

Q: WHAT IF THE CUTTERS DON'T MOVE WHEN TURNED ON?

A: The cutting unit may be dirty or clogged. Clean the unit as described previously. If this does not solve the issue please contact the REMINGTON SERVICE HOTLINE for assistance - refer to page 12.

Q: WHAT IF THE UNIT DOESN'T WORK AT ALL WHEN TURNED ON?

A: The groomer might simply need charging. Follow instructions for charging as described previously - refer to page 4. Should charging prove unsuccessful, contact the REMINGTON SERVICE HOTLINE for assistance - refer to page 12.

Q: WHAT IF THE UNIT FAILS TO HOLD A CHARGE?

A: Fully discharge the groomer by running until it completely stops. Next, follow recharging instructions described previously. If time between recharging cycles fails to increase, the battery might require replacement. Contact the REMINGTON SERVICE HOTLINE for assistance - refer to page 12.

BATTERY DISPOSAL

NOTE: The battery is not intended to be removed or replaced under normal use. The only time the battery should be removed or the unit opened or disassembled, is at the end of the product's useful life before it is discarded.

The MB061AU contains a lithium-ion battery. Once the product has reached the end of its life, to ensure proper disposal of the product, please take the appliance to a recycling centre, where the internal rechargeable battery should be removed by a professional and recycled separately.

For more information about recycling of electrical and battery operated appliances, please contact your local council office or your household waste disposal service.

CAUTION! Do not put in the fire or mutilate your batteries when disposing as they may burst and release toxic materials. Do not short circuit as it may cause burns.



This product is suitable for use in the bath or shower.

This product conforms to radio frequency interference requirements.

Any product purchased and used commercially carries a limited 90 Day Warranty.

Spectrum Brands Australia Pty Ltd and Spectrum Brands New Zealand Limited
WARRANTY AGAINST DEFECTS

In this warranty:

Australian Consumer Law means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010;

CGA means the New Zealand Consumer Guarantees Act 1993;

Goods means the product or equipment which was accompanied by this warranty and purchased in Australia or New Zealand, as the case may be;

Manufacturer, We or us means:

1. for Goods purchased in Australia, Spectrum Brands Australia Pty Ltd ACN, 007 070 573; or
2. for Goods purchased in New Zealand, Spectrum Brands New Zealand Limited, as the case may be, contact details as set out at the end of this warranty;

Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia or in New Zealand; and

You means you, the original end-user purchaser of the Goods.

1. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law, or the CGA. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. The benefits provided by this Warranty are in addition to all other rights and remedies in respect of the Goods which the consumer has under either the Australian Consumer Law or the CGA. The original purchaser of the Goods is provided with the following Warranty subject to the Warranty Conditions:
3. We warrant the Goods for all parts defective in workmanship or materials for the period of five (5) years from the date of purchase (**Warranty Period**). If the Goods prove defective within the Warranty Period by reason of improper workmanship or material, we may, at our own discretion, repair or replace the Goods without charge.

Warranty Conditions

4. The Goods must be used in accordance with the manufacturer's instructions. This Warranty does not apply should the defect in or failure of the Goods be attributable to misuse, abuse, accident or non-observance of manufacturer's instructions on the part of the user. As far as the law permits, the manufacturer does not accept liability for any direct or consequential loss, damage or other expense caused by or arising out of any failure to use the Goods in accordance with the manufacturer's instructions.
5. Exhaustible components (such as shaver heads, cutters and foils) of the Goods are included under this Warranty only where there is a defect in workmanship or materials used.
6. The warranty granted under clause 3 is limited to repair or replacement only.
7. Any parts of the Goods replaced during repairs or any product replaced remain the property of the manufacturer. In the event of the Goods being replaced during the Warranty Period, the warranty on the replacement Goods will expire on the same date as for the Warranty Period on the original Goods which are replaced.

8. In order to claim under the warranty granted under clause 3 you must:
 - (a) Retain this warranty with your receipt/proof of purchase; and
 - (b) Return the Goods to us at the relevant address below or to the Supplier by prepaid freight within the Warranty Period accompanied with (i) the legible and unmodified original proof of purchase, which clearly indicates the name and address of the Supplier, the date and place of purchase, the product name or other product serial number and (ii) this warranty.
9. This warranty is immediately void if:
 - (a) Any serial number or appliance plate is removed or defaced;
 - (b) The Goods have been serviced or otherwise repaired by a person not authorised to do so by us or where non approved replaced parts are used.
10. The Goods are designed for domestic use only. A limited 90-day Warranty applies to any industrial or commercial use of the Goods. The Goods must be connected to the electrical voltage requirements as specified in the ratings label located on the Goods.
11. This warranty does not cover the cost of claiming under the warranty or transport of the Goods to and from the Supplier or us.
12. This warranty is only valid and enforceable in Australia against Spectrum Brands Australia Pty Ltd and in New Zealand against Spectrum Brands New Zealand Limited.

Contact us or the Supplier for further details.

Spectrum Brands Australia Pty Ltd

Locked Bag 3004

Braeside, VIC 3195

AUSTRALIA

Customer service in Australia: 1800 623 118

E-mail: consumer.enquiry@remington-products.com.au

Website: www.remington-products.com.au

Spectrum Brands New Zealand Limited

PO Box 9817

Newmarket, Auckland 1149

NEW ZEALAND

Customer service in New Zealand: 0800 736 776

E-mail: info@remington.co.nz

Website: www.remington.co.nz

REMINGTON®

REMINGTON SERVICE HOTLINE

📞 Australia 1800 623 118 (toll free)

📞 New Zealand 0800 736 776 (toll free)

® Registered Trademark of Spectrum Brands, Inc., or one of its subsidiaries

Made in China to the specifications of Spectrum Brands, Inc.

© 2017 Spectrum Brands, Inc.

REV: 07/17

PART NO: T22-0004979

