

REMINGTON®

DURABLADE

TRIM · SHAPE · SHAVE

MB040
MB060



Use and Care Guide

Register Your New Product Today!

By registering your new Remington® product, you will receive these important benefits:
Proof of Ownership • Product Protection • Product Registration • Special Offers
Register online at: RemingtonProducts.com

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be observed, including the following.

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE.

DANGER

To reduce the risk of electric shock:

- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not place or drop into water or other liquid.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Except when charging, always unplug this appliance from the USB port immediately after using.
- Unplug this appliance before cleaning it.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

- This appliance is for household use only.
- An appliance should never be left unattended when it's plugged in, except when charging a rechargeable appliance.
- Close supervision is necessary when this appliance is used by, on, or near children or persons with special needs or certain disabilities.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Spectrum Brands, Inc.
- Keep the cord away from heated surfaces.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
- Never drop or insert any object into any of the appliance's openings.

- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 140°F (60°C).
- Do not use this appliance with a damaged or broken cutter unit, as injury may occur. Always make sure blades are aligned properly.
- Always attach plug to appliance, then USB charging cable to USB port. To disconnect, turn all controls to OFF, then remove USB charging cable from USB port, then detach USB charging cable from the clipper for storage.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.



This groomer is a wet/dry appliance, the hand-held part of which may be used in a bath or shower.

SAVE THESE INSTRUCTIONS

Product Features



Product Features

- 1. 39mm Blade
- 2. Trimmer head
- 3. On/Off Switch
- 4. Power port
- 5. LED charging indicator
- 6. Guide combs (1, 2, 4mm)
- 7. Guide combs (MB040 only: 6mm)
- 8. USB charging cable
- 9. Detail attachment (MB060 only)

Charging

Note: It is recommended to fully charge your appliance before using for the first time. Please refer to the charge times shown in this book.

- Ensure the product is switched off.
- Connect the product to the USB cable and then connect the USB end of the cable to a powered USB port.
- Run time from fully charged is up to 60 minutes.
- Charge time from empty is 4 hours.

Note: To preserve the life of your batteries, let them run out every 6 months then fully charge.

Charge level indicators

Charge Level	Indicator
Charging	LED shows solid
Full Charge	LED will turn off

How To Use

- Switch the product on by pressing the On/Off button.
- Always comb your beard or mustache with a fine comb before you start trimming.

Attaching and Removing Trimming Head

NOTE: Always ensure the groomer is switched off before changing any attachments.

- To remove, rotate the head counter-clockwise until it unlocks and then lift off groomer.
- To attach, place the trimming head on top of the groomer and rotate the head clockwise until it locks into place.

To Trim the Beard

- Select your desired trimming length comb. If you are trimming for the first time start with the maximum trimming length setting.
- Turn the unit on.
- Place the flat top of the fixed comb against the skin.
- Slowly slide through the hair against the direction of growth. Repeat from different directions as necessary.
- If hair builds up in the trimmer comb during the trimming process, switch the unit off, pull off the comb and brush the hair off.

How To Use

To Get a Shaven Look

- To trim any length of beard or stubble hair for a clean, shaven look then follow the above steps without a comb attached to the blade head.
- Place the flat top of the blade against the skin and slowly slide through the hair against the direction of growth.

Note: When the hair has a considerable length use the cutter in a vertical direction from bottom to top.

Trimming with Shaving Gel

- Follow the same instructions as dry shaving if using shaving gel.

Caution: After use with gel, please rinse the blade under warm water to clean away any excess gel and debris.

- To keep the unit in optimal condition we recommend re-oiling the blades after cleaning. Place a few drops of cutter or sewing machine oil onto the blades. Wipe off excess oil.

Edging

- Use the groomer without a comb.
- Hold the groomer with the edge of the blade perpendicular to the skin.
- With the cutting blade resting lightly against your skin, use slow controlled movement to create a beard/moustache line.
- For smaller, more precise areas, use the detail attachment (MB060 only)

Cleaning, Care and Maintenance

- To ensure long lasting performance of the groomer, clean after each use.
- The easiest and most hygienic way to clean the groomer is by rinsing the head under the tap after use while the blades are running.

Troubleshooting

Q: WHAT IF THE CUTTERS DON'T MOVE WHEN TURNED ON?

A: The cutting unit may be dirty or clogged. Clean the trimmer as described previously.

Q: WHAT IF THE TRIMMER DOESN'T WORK AT ALL WHEN TURNED ON?

A: The trimmer might simply need charging. Follow instructions for charging as described previously. Should charging prove unsuccessful, contact customer service at 1-800-736-4648 in the U.S. or Canada.

Q: WHAT IF THE TRIMMER FAILS TO HOLD A CHARGE?

A: Fully discharge the trimmer by running until completely stopped. Next, follow recharging instructions described previously. If time between recharging cycles fails to increase, the battery might require replacement. Contact customer service at 1-800-736-4648 in the U.S. or Canada.

Product Disposal

Battery Removal:

- The battery must be removed from the appliance before it is scrapped.
- The appliance must be disconnected from the power outlet when removing the battery.
- Ensure the trimmer is discharged of all power.
- Remove the comb attachment.
- Detach the blade head.
- Pry off the bottom gap below the grips.
- Press in exposed tabs and pull internal frame out.
- Disconnect the battery from the circuit board and internal frame.
- The battery is to be disposed of safely

CAUTION: THIS LITHIUM BATTERY MUST BE RECYCLED OR DISPOSED OF IN ACCORDANCE WITH STATE AND LOCAL REGULATIONS.

Do not burn or mutilate, as they may burst or release toxic materials. Do not short-circuit, as this may cause burns.

Warranty

Limited Five-Year Warranty

Spectrum Brands, Inc. warrants this product against any defects that are due to faulty material or workmanship for a five-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse. If the product should become defective within the warranty period, we will replace it free of charge. Return your product and sales receipt with your name, address and day time phone number to: Remington Returns Center, 507 Stokely Dr., P.O. Box 1, Deforest, WI 53532. For more information call 800-736-4648 in the U.S. or Canada. Warranty excludes: blade

KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.

This warranty does not cover products damaged by the following:

- Accident, misuse, abuse or alteration of the product
 - Servicing by unauthorized persons
 - Use with unauthorized accessories
 - Connecting it to incorrect current and voltage
 - Wrapping cord around appliance causing premature wear and breakage
 - Any other conditions beyond our control
- No responsibility, obligation, or liability is assumed for the installation or maintenance of this product.

SPECTRUM BRANDS, INC. SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO FIVE YEARS FROM DATE OF ORIGINAL PURCHASE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

Spectrum Brands, Inc. Money-back Offer

If within 30 days after you have purchased your Remington® branded product, you are not satisfied and would like a refund, return it with the sales slip indicating purchase price and date of purchase to the retailer from whom it was

purchased. Spectrum Brands, Inc. will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee, please call 800-736-4648 in the U.S. or Canada.

Remington Guarantees Satisfaction After 30 Days!

Remington 60-Day Money Back Guarantee*

If within 60 days after purchasing any Remington® branded product, you are not completely satisfied and would like a refund, return it with the original dated sales receipt directly to Remington and receive a full refund.** For questions concerning the money-back guarantee, please call 800-736-4648 in the U.S. or Canada.

*Applies to U.S. and Canadian customers' returns only.

**Terms and conditions apply.

Terms and Conditions

1. Refund will be in the form of a check issued in U.S. Dollars and will be provided only if all Terms and Conditions are met.
2. The following items must be returned to Remington and postmarked no later than 60 days after purchase of the Remington® branded product:
 - a. The Remington® product;
 - b. The original sales receipt indicating price and date purchased; and
 - c. The completed 60-day money back guarantee form located at **RemingtonProducts.com/60day.**
3. In addition, Remington, in its discretion, must determine that the returned product was used in accordance with the instruction booklet (included with the product at the time of purchase).
4. Returns should be mailed prepaid (no collect returns accepted) to:
Remington 60-Day MBG
507 Stokely Drive, Box 1
DeForest, WI 53532
5. Refund does not include postage costs for the return of the product, but will include applicable taxes paid by customer, if any.
6. No responsibility will be accepted for late, lost, stolen, misdirected or damaged product.
7. Please allow 4–6 weeks to receive your refund by check.

Questions or comments: Call 800-736-4648 in the U.S. or Canada or visit **RemingtonProducts.com.**

Dist. by: Spectrum Brands, Inc., Middleton, WI 53562

© Registered Trademark of Spectrum Brands, Inc.

© 2017 Spectrum Brands, Inc. 6/17 17562-00

Made in China.

T22-0005183-A